


# EIT<sup>®</sup> UVKEY<sup>™</sup> QUICK START GUIDE

1

## INITIAL USE

Press and hold RESET  for 8 seconds to initialize unit\*.

2

## SINGLE-BUTTON OPERATION

- A short press (<1 sec) displays current reading.
- A long press (>1 sec) resets reading to zero.

3

## MEASURE

Unit collects and displays UV radiant exposure in Joules/cm<sup>2</sup>.

4

## SUPPORT

Visit [www.eit.com](http://www.eit.com) for User's Guide, or email [uv@eit.com](mailto:uv@eit.com).



*\*Initializing unit will start the calibration validity timer.*